

Explorer 100 Series – 16 FREQUENCY CHART

Frequency Range 555-579 MHz

Operating Frequencies					
		Channel			Channel
1	555.125	28/1	9	566.000	30/1
2	555.375	28/2	10	570.250	30/2
3	556.250	28/3	11	571.125	30/3
4	559.000	28/4	12	572.250	31/1
5	559.250	28/5	13	575.500	31/2
6	561.500	29/1	14	577.500	31/3
7	562.000	29/2	15	578.000	32/1
8	564.500	29/3	16	579.250	32/2



MICRON HOUSE TELEPHONE: +44 (0) 20 8341 3500
3 NEW ROAD FACSIMILE: +44 (0) 20 8341 5100
LONDON N8 8TA E-MAIL: sales@micronwireless.co.uk
UNITED KINGDOM WEBSITE: www.micronwireless.co.uk