

# Explorer 700 Series – 16 FREQUENCY CHART

## Frequency Range 722-746 MHz

Operating Frequencies					
		Channel			Channel
<b>1</b>	722.100	56/1	<b>9</b>	734.100	58/1
<b>2</b>	724.100	56/2	<b>10</b>	736.100	58/2
<b>3</b>	725.700	56/3	<b>11</b>	737.700	58/3
<b>4</b>	726.300	56/4	<b>12</b>	738.300	58/4
<b>5</b>	728.100	57/1	<b>13</b>	740.100	59/1
<b>6</b>	730.100	57/2	<b>14</b>	742.100	59/2
<b>7</b>	731.700	57/3	<b>15</b>	743.700	59/3
<b>8</b>	732.300	57/4	<b>16</b>	745.850	59/4



MICRON HOUSE TELEPHONE: +44 (0) 20 8341 3500  
3 NEW ROAD FACSIMILE: +44 (0) 20 8341 5100  
LONDON N8 8TA E-MAIL: [sales@micronwireless.co.uk](mailto:sales@micronwireless.co.uk)  
UNITED KINGDOM WEBSITE: [www.micronwireless.co.uk](http://www.micronwireless.co.uk)